IR remote control for users

351-25310

4 year warranty

AUTO: Activate automatic mode
• Press this button to activate the automatic mode.

ON: Switch on light for 6 hours
• Press this button to switch the light on constantly for 6 hours. After that time, the detector resumes its automatic operation. Please note: this button cannot be used if the TIME setting is on pulse.

OFF: Switch off light for 6 hours
• Press this button to switch the light off completely for 6 hours. After that time, the detector resumes its automatic operation. Please note: this button cannot be used if the TIME setting is on pulse.

Technical data

IR remote control for users

CE

Dimensions

niko