

# Single key for 'up' and 'down' arrows for push button with 2 control buttons and 1 or 2 feedback LEDs, cream.

**100-00027**

**4** year warranty

Single key for a bus push button with 2 control buttons and 1 or 2 feedback LEDs. The key is equipped with "up" and "down" arrows. Farve: cream.

## Tekniske data

Single key for 'up' and 'down' arrows for push button with 2 control buttons and 1 or 2 feedback LEDs, cream.

- Funktion: Tangent til en Nikobus-trykknop eller en RF-vægsender.
- Antal betjeningstryk: 1 kontrolknop
- Materiale centralplade: Centralpladen er fremstillet af hård PC og ASA. Monteringsunderlagets materiale er gennemfarvet.
- Farve: cream (gennemfarvet, omtrent RAL 1013)
- Udskrift: På hver tast på centralpladen er symbolerne "op" og "ned" præget permanent.
- Linse: Knappen på centralpladen er udstyret med 2 rektangulære, transparente linser.
- Demontering: For at afmontere skal du blot trække centralpladen af mekanismen.
- Kapslingsklasse: IP41 for kombinationen af en mekanisme, centralplade og en forsænket surroundplade
- Vandalklasse: Efter montering garanteres en slagfasthed på IK06.
- Brandsikkerhed
  - Centralpladens plasticdele er selvslukkende (overholder en glødetrådtest på 650 °C)
  - Centralpladens plasticdele er halogenfri.
- Dimensioner på færdiggørelse: 45 x 45 mm (HxW)
- Godkendelse: CE

